

# TRANSPORTING DRY EXCAVATED MATERIALS & SPOILS

## 1. Preparation

- a. Utilize truck with proper containment of materials.
- b. Determine disposal site of excavated materials.
- c. Determine the path of travel to and from disposal site.

## 2. Process

- a. Load.
- b. Check truck after loading for possible spillage.
- c. Transport in manner to eliminate spillage & tracking.
- d. Utilize one route for transporting.

## 3. Clean-up

- a. Clean loading area.
- b. Clean transporting route using dry methods such as sweeper truck and broom.
- c. Wash off truck and other equipment in a truck wash bay at public works.